

## BLANKET INSTALLATION

Thank you for using the Astro-Cooler® Blanket. It has been designed for easy installation. Please follow these instructions.

**Prior to Installation:** Place cardboard buffer between front wall and first pallet.

### STEP 1

Center the blanket on top of the first two pallets. Unfold the blanket so that both edges are evenly spaced against the side walls. You may choose to tuck a small amount of the blanket between the first two pallets and the nose of the truck or container to prevent any movement during transit.



### STEP 2

As you load each additional row of pallets, pull the blanket out over them until you reach the back of the load.



### STEP 3

At the tail, pull the blanket down to the floor of the trailer. Tuck the blanket in on the floor and walls near the floor.



### STEP 4

Close the trailer doors.  
You are finished!



### Optional Installation:

A Rope-Pull option is available if you prefer to load the blanket on the first two pallets, and then load the balance of the trailer. After fully loaded, the blanket may be pulled out at one time with a rope all the way to the back of the load.



---

## BLANKET REMOVAL & STORAGE

### STEP 1

Pull blanket entirely out face up.

### STEP 2

Fold in half so ends are flush - fabric has “memory” so creases will align.

### STEP 3

Fold in half again, this time leaving a three foot section exposed.

### STEP 4

Repeat *Step 3* several times until you have one four foot section plus three foot exposed section.

### STEP 5

Fold over three foot exposed section.

### STEP 6

Tri-Fold and stack on pallet for storage.



Blankets Folded, Palletized & Ready for Storage