

Astro-Cooler® Blanket Installation, Removal & Storage

9'x 53' Thermal Reflective Cargo Blankets
18 per pallet

To Order Please Contact:

orders@astrocooler.com

Tel : 1-800-442-3645

Fax : 916-381-1575

For full video instructions go to:
<http://astrocooler.com/video.html>

Astro-Cooler® Cargo Insulation

BLANKET INSTALLATION

Prior to Installation

Protect the nose with cardboard buffer.



STEP 1

Center the blanket on top of the first two pallets. Unfold the blanket so that both edges are evenly spaced against the side walls. You may choose to tuck a small amount of the blanket between the first two pallets and the nose of the truck or container to prevent any movement during transit.



STEP 2

As you load each additional row of pallets, pull the blanket out over them until you reach the back of the load.



STEP 3

At the tail, pull the blanket down to the floor of the trailer. Tuck the blanket in on the floor and walls near the floor.



STEP 4

Close the trailer doors.
You are finished!



Optional Installation:

A Rope-Pull option is available if you prefer to load the blanket on the first two pallets, and then load the balance of the trailer. After fully loaded, the blanket may be pulled out at one time with a rope all the way to the back of the load.



BLANKET REMOVAL & STORAGE

STEP 1

Pull blanket entirely out, foil facing up.

STEP 2

Be sure the “Nose” sticker is on the end you are folding.



STEP 3

Begin folding “accordion” style, leaving a two foot section exposed.

STEP 4

Repeat *Step 3* several times until you have one accordion section plus a two foot exposed section.

STEP 5

Fold over two foot exposed section.

STEP 6

Tri-Fold and stack on pallet for storage.



Blankets Folded, Palletized & Ready for Storage

